

DO IT YOURSELF



Stainless Steel

BUSHFIRE MESH

DIY 5 Step Residential Guide

SHIELDS AGAINST
THE 3 THREATS
OF BUSHFIRE



**SHIELD
PROTECTION**



EMBER
ATTACK



RADIANT
HEAT



DIRECT
FLAME

WHEN CONSIDERING
BUSHFIRE MESH,
USE THIS FIVE STEP
GUIDE TO HELP YOU

- 1 Identify
- 2 Select
- 3 Install
- 4 Maintain
- 5 Order



Exceeds AS 3959

2024



stainless steel
WIRE & MESH

Copyright

©2022 SSWM to the extent permitted by law, all rights are reserved, and no part of this publication covered by copyright may be reproduced or copied in any form or by any means except with the written permission of SSWM.

Disclaimer

Stainless Steel Wire & Mesh Pty Ltd (SSWM) advises that the contents of this guide are intended and provided for information purposes only. Anyone using this guide should take reasonable care when using it and should obtain professional advice if uncertain about the application of the information to their particular circumstance. Moreover, the guide is provided on the basis that any person relying on the information undertakes responsibility for assessing the relevance and application of its content. The reader is advised and needs to be aware that such information may be incomplete or unable to be used in any specific situation. Whilst every effort has been made to ensure that the material is accurate and up to date at the time of publication, SSWM do not guarantee or warrant the accuracy, completeness, or currency of the information provided.

No reliance or actions must, therefore, be made on the information contained in this Residential DIY Guide without seeking prior expert professional, scientific and technical advice in relation to the specific situation and product application. To the extent permitted by law, SSWM excludes all liability to any person for any consequences, including but not limited to all losses, damages, costs, expenses and any other compensation, arising directly or indirectly from using this publication (in part or in whole) and any information or material contained in it

Additional Information

Please access referenced websites to ensure you are utilising up-to-date documents, information and advice.

Bushfire Mesh is installed to protect against embers from penetrating gaps within a home or building during a bushfire

RESIDENTIAL

SSWM Bushfire Mesh

Stainless steel Bushfire Mesh is part of the solution for your bushfire protection against ember attack and radiant heat. Bushfire Mesh is installed to protect against embers penetrating gaps within a home or building during a bushfire. Ember attack accounts for 80% of houses lost during a bushfire.

Stainless Steel Wire & Mesh (SSWM) have designed a Bushfire Mesh to suit any application, from soft to rigid and wide to narrow. The primary use of the mesh is for bushfire protection, how and where you install your mesh, will determine which mesh is most appropriate. SSWM's Bushfire Mesh is easy to handle and install for DIY projects. It is also a cost-effective option.

Once you have selected the most appropriate mesh for your project, it is time to consider your design and install options, this has been driven by AS 3959-2018 Construction of buildings in bushfire-prone areas.

AS 3959-2018 Construction of buildings in bushfire-prone areas

Following the devastating 2009 Bushfires AS3959-2018 Construction of buildings in bushfire-prone areas was developed. The standard requires a mesh to be used for screens or closing gaps greater than 3mm.

SSWM Bushfire Mesh range has been independently tested by CSIRO and met the physical properties of AS3959-2018.

- ✓ Mesh with max aperture of 2mm
- ✓ Corrosion resistant steel
- ✓ Non-combustible

SSWM Bushfire Mesh can be used in all applications:

- That require a gap of greater than 3mm to be closed by a mesh (as above)
- The gap between the perimeter of the mesh and the building element that it is fitted to, does not exceed 3mm

Bushfire mesh is part of your solution

Reducing your bushfire risk with Bushfire Mesh is part of your solution for lasting peace of mind for your family and home. The Country Fire Authority (CFA) and Victorian Building Authority (VBA) have aligned to provide practical advice to those wishing to better protect their homes from bushfires.

The CFA & VBA also highlight that reducing the risk from bushfires comprises a number of processes and tasks:

1. Assessing and managing site vegetation
2. Defendable space assessment and maintenance
3. Provision and maintenance of active protection equipment
4. Constructing safety measures as outlined in this guide

For further information on retrofitting your home refer to

VICTORIAN BUILDING AUTHORITY (VBA)

- > *A guide to retrofit your home for better protection from a bushfire*
Mesh is referenced on pages 6 -14
- > *A guide to retrofit class 9 buildings*
Mesh is referenced on pages 6 - 9

QUEENSLAND RECONSTRUCTION AUTHORITY QUEENSLAND GOVERNMENT

- > *Bushfire Resilient Building Guidance for QLD Homes*
Mesh is referenced on pages 20, 48 - 89

FIRE PROTECTION AUSTRALIA (FPA)

- > *Bushfire Planning and Design (BPAD) Accredited Practitioners resource*

COMMONWEALTH SCIENTIFIC AND INDUSTRIAL RESEARCH ORGANISATION (CSIRO)

- > *A bushfire best practice guide*

BUSHFIRE BUILDING COUNCIL AUSTRALIA

- > *Newbuilds & Retrofits*



*SSWM Bushfire Mesh
can be used to meet
the requirements
of AS3959-2018
for BAL 12.5 FZ,
where mesh
is specified*

RESIDENTIAL

Further Information from Australian State & Territory Fire Services


This information is to be used as a guide only. SSWM Bushfire Mesh can be used to meet the requirements of AS3959-2018 for BAL12.5-FZ, where mesh is referenced and if the prescribed construction requirements are met. The Australian Standard (AS3959-2018) Construction of buildings in bushfire-prone areas uses a scale referred to as the Bushfire Attack Level (BAL). It is a means of measuring the severity of a building's potential exposure to ember attack, radiant heat, and direct flame contact. The Flame Zone (FZ) is the highest level of bushfire attack.

Installation requirements can vary depending on factors such as application, environment, local planning and building regulations etc. To maintain their currency, all Australian Standards are periodically reviewed, and new editions are published. Between editions, amendments may be issued.

Before commencing your installation, you should consult a Fire Protection Australia (FPA), Bushfire Planning and Design (BPAD) Accredited Practitioner and contact your local council and fire authority to ensure you are meeting all the building and AS3959-2018 requirements.

Australian State & Territory Fire Services

- | | |
|-----|--|
| VIC | <ul style="list-style-type: none"> > Country Fire Authority (CFA) > Your Guide to Property Preparation |
| NSW | <ul style="list-style-type: none"> > Rural Fire Service (RFS) > Best Practice Guide for Bushfire Protection > Planning for Bushfire Protection |
| QLD | <ul style="list-style-type: none"> > Fire & Emergency Services (QFES) > Prepare For Bushfire Season |
| WA | <ul style="list-style-type: none"> > Department of Fire & Emergency Services (DFES) > Prepare for a Bushfire |
| TAS | <ul style="list-style-type: none"> > Tasmanian Fire Service > Bushfire Survival Plan |
| SA | <ul style="list-style-type: none"> > Country Fire Service (CFS) > Building in Bushfire Prone Areas |
| ACT | <ul style="list-style-type: none"> > Rural Fire Service / ACT Emergency Services Agency (ACT ESA) > Bushfire Ready and Bushfire Preparedness Tips |
| NT | <ul style="list-style-type: none"> > Fire & Rescue Service / Police, Fire & Emergency Services (PFES) > Prepare and Plan for Bushfires |




To assist with your selection you can order samples or watch our product videos

RESIDENTIAL

1. IDENTIFY APPLICATIONS

Identify your applications as per various sections of AS3959-2018.



2. SELECT SSWM BUSHFIRE MESH

SSWM comes in different widths and lengths and allows customisation to protect your space.




























Application

1. Vents & Weepholes
2. Screens for Windows & Doors
3. Roofs
4. Evaporative air cooling system
5. Eaves & Awnings
6. Subfloor spaces Verandahs & Decks
7. Gutter & Valley Leaf Guard
8. Perimeter Fence

Product Specification

Flexi or Tough
 Flexi, Tough or Extreme
 Flexi or Tough (determined by flexibility)
 Tough or Extreme
 Flexi or Tough
 Flexi or Tough (determined by flexibility)
 Tough (must be removable for cleaning)
 Tough

PRODUCT COMPARISON & SELECTION

	 FLEXI - Shield	 TOUGH - Shield	 EXTREME - Shield	 ULTIMATE - Shield
	ORDER ONLINE SSWOB 01230	ORDER ONLINE SSWOB 01670 SSWO 01670	SSWOBS 01510	SSWO 01640
BAL Low - FZ (typically installed)	Low, 12.5	12.5, 19, 29 & 40	40, FZ	40, FZ
Secondary Application	 Insect Mesh	 Pet Mesh	 Security Mesh	 Industrial Mesh
PRODUCT SPECIFICATIONS				
Price Indicator	\$	\$\$	\$\$\$	\$\$\$\$
Roll or Sheet / Cutting	 	 	 	 
Finish	● Black (316)	● Black (316) ● Stainless Steel (304/316)	● Black (316)	● Stainless Steel (304/316)
Formability (handling)	Malleable - SOFT	Self Supporting - FLEXIBLE	Self Supporting - RIGID	Self Supporting - RIGID
Aperture x Wire Diameter	1.23 x 0.18 mm	1.67 x 0.45 mm	1.51 x 0.80 mm	1.64 x 0.90 mm
Open Area % <i>Pre black powder coat finish</i>	76 %	62 %	43 %	42 %
QUALITY ASSURED ✓ Compliant ✓✓ Tested ✓✓✓ Certified				
AS 3959-2018 Compliant 	✓	✓	✓	✓
CSIRO FCO-3313 Rev B Independently verified 	✓	✓	✓	✓
AS/NZS 1530.3:1999 Ignitability 	✓✓	✓✓	✓✓	
AS 2331 1.3.1 2001 Neutral Salt Spray Test 		✓✓	✓✓	
AS 5041 2003 Knife Shear Test 			 SHIELD PROTECTION	✓✓
SHIELD PROTECTION				
USQ Project 1007952 Ember Attack 	✓✓	✓✓✓	✓✓✓	✓✓✓
AS 1530.8.1 Radiant Heat 		✓✓	✓✓	✓✓
ASTM E2886 Direct Flame 		✓✓✓	✓✓✓	✓✓✓
DIMENSIONS W x L				
 Australian Standards: SSWM bushfire mesh can be used to meet the requirements of AS3959-2018 for BAL 12.5 -FZ, where mesh is referenced and if the prescribed construction requirements are met.	610 mm x 30 m	190 mm x 30 m ✓	750 mm x 2000 mm	915 mm x 30 m
	915 mm x 15 m	610 mm x 30 m ✓	750 mm x 2400 mm	1245 mm x 30 m
	915 mm x 30 m	915 mm x 15 m ✓	900 mm x 2000 mm	1550 mm x 30 m
	1220 mm x 15 m	915 mm x 30 m ✓✓	900 mm x 2400 mm	
 Independently Verified: SSWM Bushfire Shield Mesh range has been independently verified by CSIRO and met the physical properties of AS3959-2018. ✓ Mesh with max aperture of 2mm ✓ Corrosion resistant steel ✓ Non combustible	1220 mm x 30 m	1245 mm x 15 m ✓	1200 mm x 2000 mm	
	1550 mm x 15 m	1245 mm x 30 m ✓✓	1200 mm x 2400 mm	
	1550 mm x 30 m	1550 mm x 15 m ✓	1500 mm x 2000 mm	
		1550 mm x 30 m ✓✓	1500 mm x 2400 mm	
		1830 mm x 30 m ✓		



Bushfire Mesh installation is straightforward, using tools that are commonly available

RESIDENTIAL

3. INSTALL

3.1 SELECT APPROPRIATE TOOLS

Your mesh selection will determine the most appropriate tools for ease of cutting and installation:

The following tools are commonly used for installation and are provided as a guide

- Gloves
- Safety glasses
- Tape measure
- Straight edge
- Staple gun
- Staples
- Clamps
- Screw drivers
- Screws



FLEXI - Shield

Drill, Scissors


TOUGH - Shield

Drill, Tin snips

EXTREME - Shield

Drill, Angle grinder, Ear protection

When referring to Residential DIY Guide, make sure you use all equipment, including PPE, safely by following the manufacturer's instructions. Check that the equipment is suitable for the task and that PPE fits correctly. If you are unsure, contact a professional.




*TIP: Measure your
Bushfire Mesh
twice and cut
once!*

RESIDENTIAL

3.2 MEASURE

Create an effective work area and consider the following options:

- Homemade stands
- Light background so wire of bushfire mesh is visible for cutting
- Clamps to hold mesh in position



3.3 CUT MESH

FLEXI - Shield
Scissors




TOUGH - Shield
Tin Snips



EXTREME - Shield
Grinder





Bushfire Mesh can be retrofitted to existing structures by bending and folding


RESIDENTIAL

3.4 BEND AND / OR FOLD TO FIT SHAPE

Mesh may have to be bent or folded to fit to shape. The below have been bent by hand as examples.

FORMABILITY RIGIDITY Bend and/or Fold


FLEXI - Shield




Malleable SOFT




TOUGH - Shield




Self Supporting FLEXIBLE



EXTREME - Shield



Self Supporting RIGID






*Bushfire Mesh is
easy to handle
and install for
DIY projects*

RESIDENTIAL

3.5 FIXING OPTIONS

The following fixing options are commonly used and provided as a guide only:



*Fixed to Frame

APPLICATION	FLEXI	TOUGH	EXTREME
1. Vents & Weepholes	Silicone Nails Screws	Silicone Nails Screws Tie Wire	<i>Not Commonly Used</i>
2. Screens for Windows & Doors	Spline	Nails Screws*	Nails Screws*
3. Roofs	Nails Screws Staples	Nails Screws	<i>Not Commonly Used</i>
4. Evaporative air cooling system	<i>Not Commonly Used</i>	Silicone*	<i>Not Commonly Used</i>
5. Eaves & Awnings	Nails Screws Staples	Nails Screws	<i>Not Commonly Used</i>
6. Subfloor spaces Verandahs & Decks	Nails Screws Staples	Nails Screws Staples	<i>Not Commonly Used</i>
7. Gutter & Valley Leaf Guard	<i>Not Commonly Used</i>	Screws	<i>Not Commonly Used</i>
8. Perimeter Fence	<i>Not Commonly Used</i>	Tie Wire	<i>Not Commonly Used</i>



*Further installation
considerations to
be aware of*

RESIDENTIAL

3.6 FURTHER INSTALLATION CONSIDERATIONS

IMPORTANT STAINLESS STEEL FABRICATION INFORMATION

Stainless steel can be contaminated by carbon steel which will lead to corrosion. Ideally, a fabricator will have a dedicated workshop and tools for stainless steel only.

Contamination can be picked up from:

- Grinding wheels, wire brushes and finishing belts
- Steel storage racks
- Tooling used with other metals
- Contamination from grinding or welding sparks from nearby carbon steel fabrication

ARCHITECTURAL WOVEN MESH

If the mesh is not black powder coated and is being used externally for aesthetic purposes, to minimise tea staining please evaluate if the mesh is to be pickled, passivated and electropolished.

HEALTH & SAFETY

Asbestos, lead-based paints and copper chromium arsenic (CCA) treated timber are health hazards you need to look out for when retrofitting older homes. These substances can easily be disturbed when renovating and exposure to them can cause a range of life-threatening diseases and conditions including cancer. For information on the dangers of asbestos, lead-based paint and CCA treated timber and tips for dealing with these materials contact your local council's Environmental Health Office.



*Cleaning is simple!
Wash with mild
detergent and
warm water*

RESIDENTIAL

4. MAINTAIN

Bushfire Mesh is part of the solution to your bushfire protection and will be protecting your assets once you have completed steps 1-3 - congratulations! It is important to regularly maintain your Bushfire Mesh as part of your bushfire protection against ember attack.


Bushfire Mesh is incredibly durable due to its corrosion resistance and non-combustibility. Bushfire Mesh is manufactured from stainless steel, a low maintenance material, however, not maintenance free. Regular maintenance and inspections of your Bushfire Mesh are essential to ensure it functions as intended to overcome the following that can occur with Bushfire Mesh:

- Acting as a filter and catching naturally occurring airborne deposits such as salt, moisture and dust that can leave stains and marks
- Build-up of debris and dust around applications that require airflow
- Being damaged by machinery for applications that require machinery to be used in close proximity, such as a lawnmower near subfloors & perimeter fencing applications
- Sagging or attachment issues due to pets and balls, for example

The cleaning frequency of stainless steel depends on four points;

1. The environment
2. Position of the Bushfire Mesh
3. Stainless steel surface finish and application use
4. Customer's expectations

A rule of thumb for cleaning external stainless steel is when you clean the surrounding windows also clean your Bushfire Mesh. Cleaning to be undertaken in accordance with the table below.



Cleaning Equipment

Environment	Grade 304	Grade 316	Cleaning
Clean inland	3 – 6 months	6 – 12 months	- Wash, both surfaces of Bushfire Mesh with soap or mild detergent and warm water
Polluted urban / Industrial	Not suitable	6 – 12 months	- Rinse with clean cold water and dry
Coastal / Marine (not splashed)	Not suitable	3 – 6 months	- Never use abrasive or solvent-based cleaners, as they can damage the stainless steel and powder coat finish

Source: Adapted from ASSDA



*Contact the SSWM
sales team for a
seamless sales
experience*

5. ORDER



**Australia's leading stockist & innovator
of Stainless Steel Bushfire Mesh**

Extensive Stock Holding

Online ordering

www.bushfiremesh.com.au

- Freight friendly FLEXI & TOUGH Mesh 15m rolls available for same day despatch to rural areas



FLEXI - Shield




915 mm W
15 m L

ORDER ONLINE



MOST POPULAR

TOUGH - Shield





915 mm W
15 m L

ORDER ONLINE



EXTREME - Shield





750 mm W
2,000 mm L

LEARN MORE




*This family now has
peace of mind after
retrofitting
Bushfire Mesh at
their property
in rural
Victoria*

CASE STUDY 1

RANGE OF BUSHFIRE MESH APPLICATIONS

Woodend, Victoria





These Bushfire Mesh windows were successfully installed as a weekend project by a handy couple


CASE STUDY 2

BUSHFIRE MESH SCREENS FOR WINDOWS & DOORS

Gippsland, Victoria



Screens for Windows & Doors, TOUGH



TOUGH



TOUGH



Screens for Windows & Doors, TOUGH



TOUGH




*This was a
simple and
straight forward
subfloor
retrofit*

CASE STUDY 3

BUSHFIRE MESH SUBFLOOR *Hesket, Victoria*



Subfloor FLEXI



Subfloor FLEXI



Subfloor FLEXI




*Perimeter Fencing is
an additional
barrier to
maintain your
defendable
space against
bushfires*


CASE STUDY 4

BUSHFIRE MESH PERIMETER FENCE

Woodend, Victoria



Perimeter Fence TOUGH



Perimeter Fence TOUGH



Perimeter Fence TOUGH



Quality Assured

Designed, tested and proven in Australia to Australian Standards and Australia's harsh environment.



Product Innovation

We are a major innovator in the uses of stainless steel Bushfire Mesh.



Versatile Product Range

Our range is versatile and can be customised so there is a mesh to suit any application.



Extensive Stock Holding

We are Australia's leading supplier of stainless steel Bushfire Mesh.




Speed to Market

We offer same day despatch and freight friendly rolls quickly despatched to rural areas.




AUSTRALIA'S ORIGINAL

Part of your solution for bushfire protection against ember attack and radiant heat. We also have information to assist with community, industrial / agricultural applications and architects / engineers.




Residential



Community



Industrial / Agriculture



Architects / Engineers

HEAD OFFICE & WAREHOUSE

3 Commercial Court, Tullamarine VIC 3043, Australia
t 1300 304 316 **f** 1300 305 805
Int t +613 9448 9048 **Int f** +613 8669 4506

POSTAL ADDRESS

P.O Box 358, Tullamarine VIC 3043, Australia

WHY BUSHFIRE MESH?

"SSWM has worked with Industry & Australian Universities to design a product that will stop embers and reflect radiant heat to reduce the likelihood of house fires. I am proud to be part of the solution for asset protection for the Australian community".

Andrew Greer
 SSWM Innovator & Director